

Smoke Detector

Indoor sensor

General information

The remote smoke detector can be placed up to 2000 feet away from the tattletale depending on structures and objects in-between the smoke detector and the tattletale. It used photoelectric technology to detect smoke (not heat) and it continually monitors its own sensitivity and operational status. The tattletale does not need to be armed to send a smoke alarm. The two 3.0V Lithium Batteries that are included will typically last for about 1 year.



Mounting instructions

The best location for the smoke detector is at a high point where smoke will accumulate. Locate away from air conditioners, heating registers and any other ventilation source that may interfere with smoke entering the alarm.

Remove the back mounting plate by twisting it counterclockwise. Use the provided mounting screws to attach the mounting plate to the ceiling.

Reattach the smoke detector to the mounting plate by lining up the raised tab on the lip of the smoke detector with the slot on the lip of the mounting plate and turning the detector clockwise until it snaps into place.

Changing the batteries

- You will know that the battery in the smoke detector needs to be changed when its corresponding zone light on the tattletale begins to flash rapidly and the smoke detector chirps every 30 seconds.
- Take the smoke detector off of the ceiling (or wall) and remove the battery cover.
- Replace the batteries with new ones. 3V Lithium batteries are readily available in most stores that sell batteries.
- Replace the smoke detector and test it – follow steps listed below.

General maintenance notes

Understanding the LED: Flashes every 9 seconds – operating normally. On – detects smoke. Off – Trouble or maintenance is required.

It's a good idea to clean the smoke detector's smoke entry chamber every 3 months with a vacuum cleaner or canned air. You do not need to open up any part of the smoke detector to do this.

Testing the smoke detector

IMPORTANT: When the "Silence/Test" button is pressed the tattletale will actually make a call to tattletale Dispatch. It is important that you put your account on test before you test your smoke detector.

- Call [1-888-835-5668](tel:1-888-835-5668) to put your account on test.
- Press the test button on the smoke detector. (Note the distinctive siren for the smoke detector.)
- Enter the 4 digit arming code into the tattletale to silence the siren. If the Zone 8 LED remains solid, press the # button to clear it.

**Protect Anything.
Anytime.
Anywhere.**